



## CM3D User Guide

### CM-3 Dual Conference Microphone

**The CM-3 Dual Conference Microphone includes two professional-quality microphones for use with SoniClear digital recording software. Ideal for larger boardrooms and meeting rooms.**

The CM-3 microphone system is designed to capture recordings of meetings with clean, detailed sound. The “boundary microphone” design enhances the capture of speech, while reducing the pickup of background noise. The two conference microphones connect directly to the computer and can be configured in several ways using the included extension cables and connectors.

#### Features

- Two CM-3 Conference Microphones
- Professional-quality sound
- Adapter for computer input
- Two ultra-thin 10' extension cords
- Y Adapter connects mics together

#### Benefits

- Hear voices more clearly
- Coverage for large conference tables
- Flexible layout of cables
- Small, inconspicuous appearance

#### System Requirements

- Windows XP
- Laptop or desktop computer
- Built-in or external sound system
- SoniClear recording software

more →

# **Directions For Use**

## **Dual Microphone Configuration**

For long conference tables the microphones can be connected together to pick up sound from all participants in the room. The computer can be located in the middle of the table or at either end.

### **Computer in middle**

Use the Y configuration to place the computer in the middle between the two microphones. Connect a 10' extension cord to each microphone and connect the two extension cords into the black Y adapter. Connect the Y adapter into the silver computer adapter. The silver adapter can then be connected to the microphone input of the laptop or desktop computer.

### **Computer at one end**

Use a straight-line configuration to place the computer at the end of the table, with the two microphones up to 10' and 20' away. Connect a 10' extension cord to one microphone and connect that to the black Y adapter. Connect the second microphone directly to the Y adapter. Connect the Y adapter to the second extension cord. Connect the extension cord to the silver computer adapter. The silver adapter can then be connected to the microphone input of the laptop or desktop computer.

## **Single Microphone Configuration**

The microphones can also be used separately to record in two locations, when a single microphone will provide adequate coverage. Connect a 10' extension cord to one microphone. Connect the extension cord to the silver computer adapter. The silver adapter can then be connected to the microphone input of the laptop or desktop computer. Both 10' extension cords can be used together for a 20' reach.

## **Usage Tips**

Always use the silver computer adapter as the connection to the computer. Also, do not connect the short cable attached to the microphone directly to the silver adapter. An extension cable must always be used. No sound will be picked up unless the silver adapter is properly connected.

Place the microphones away from papers that might be shuffled during the meeting. The microphones have very good coverage range (up to 20 feet in a quiet room). However, if there is a problem hearing a person who is speaking very softly, move the microphone closer to that person

## **Technical Support**

View the SoniClear Support Page at [www.soniclear.com](http://www.soniclear.com) for technical support information.