



## SC10D and SC10Q User Guide

### SC10 USB Conference Microphone Kit

**The SC10 USB Conference Microphone kit is available in two versions. The SC10D includes a base USB microphone and one extension microphone. The SC10Q includes a base USB microphone and three extension microphones, ideal for larger boardrooms.**

The SC10 microphone kit is designed to capture recordings of meetings with clean, detailed sound. The “boundary microphone” design enhances the capture of speech, while reducing the pickup of background noise. The conference microphones connect directly to the computer USB port.

#### Features

- One SC10 Base Conference Microphone
- One or Three SC10 Extension Conference Microphones
- Professional-quality sound
- Records in Stereo (left and right channels)
- Base microphone includes 9’ USB cable
- Extension microphones include 8’ cable
- Daisy-chain Extension microphones to Base microphone and to other Extensions

#### Benefits

- Hear voices more clearly
- Coverage for large conference tables
- Flexible layout of cables
- Small, inconspicuous appearance

#### System Requirements

- Windows 7, Windows XP, or Windows Vista
- Laptop or desktop computer
- Available USB Port
- SoniClear recording software

more →

# Directions For Use

## Installation

Follow the installation instructions for the SC10 microphone kit. This is located in the SoniClear Installation Guide (Meeting Recorder and Gov Recorder software), or the Court Recorder Installation Guide (Court Recorder software).

## Single Microphone Setup

The Base microphone can also be used with a single microphone, which will provide adequate coverage for smaller rooms. Connect the 9' USB cable from the Base microphone into an available USB port on the computer. For longer reach, you can connect the microphone to a standard USB extender/booster (not included), and then plug that extension cord into the computer. The Base microphone has two microphones built in for stereo pickup.

## Dual Microphone Setup

For long conference tables the microphones can be connected together to pick up sound from all participants in the room. Connect the 9' USB cable from the Base microphone into an available USB port on the computer. Connect the 8' Extension microphone cable into the right extension jack on the Base microphone (on the right side when looking at the Base from the front). The Base microphone will record as the left channel and the Extension microphone will record as the right channel.

## Quad Microphone Setup (SC10Q only)

For long conference tables the microphones can be connected together to pick up sound from all participants in the room. Connect the 9' USB cable from the Base microphone into an available USB port on the computer. Connect one 8' Extension microphone cable into the right extension jack on the Base microphone (on the right side when looking at the Base from the front). Connect a second Extension microphone to the jack on the back of the first Extension microphone. Connect a third Extension to either the jack on the back of the second Extension microphone, or to the left jack on the Base microphone.

## Usage Tips

Place the microphones away from video projectors, papers that might be shuffled during the meeting, or any other source of noise that could interfere with hearing the people speaking. The microphones have very good coverage range (up to 20 feet in a quiet room). However, if there is a problem hearing a person who is speaking very softly, move the microphone closer to that person

## Technical Support

View the SoniClear Support Page at [www.soniclear.com](http://www.soniclear.com) for technical support information.